



**18 V Cordless  
Portable Power Cleaner**

**1 Year Warranty**

See owner's manual for details.

Thank you for selecting this Nomad™ product.  
Let us help you put your Nomad together or  
answer any questions. Please do not return this  
product to the store.

Call us toll-free: Customer Service  
1-877-992-2042.

Mon. - Fri. 8:00am -7:00pm EST  
or visit our web site 24 hours a day:

[www.nomad2go.com](http://www.nomad2go.com)

Made in China ■ Hecho en China  
©2008 Royal Appliance Mfg. Co.  
All Rights Reserved.

Todos los derechos reservados.  
Part # ■ N. de pieza 1-174177-000 8/08

**Limpiadora de presión  
portátil de 18 V**

**Garantía de 1 año**

Encuentre más información en el  
manual del propietario.

Gracias por elegir este producto Nomad™.  
Permítanos ayudarle a ensamblar su Nomad  
o responder sus preguntas. No devuelva este  
producto a la tienda.

Llámenos a la línea gratuita: Servicio de  
atención al cliente 1-877-922-2042 de lunes a  
viernes de 8:00 a. m a 7:00 p m hora del este,  
o visite nuestro sitio web las 24 horas del día:

[www.nomad2go.com](http://www.nomad2go.com)

Distributed by: ■ Distribuido por:  
TTI Floor Care North America  
7005 Cochran Road  
Glenwillow, OH 44139



**18 V Cordless Portable Power Cleaner  
Limpiadora de presión portátil de 18 V**

**ON THE GO™**

# MAKE CLEANUP EASY

## Wherever The Outdoors Take You

Mud. Clay. Sand. If it's out there, an outdoorsman will find it, wear it, drive through it, or play in it. It's the price you pay when you call the middle of nowhere your playground. But now, with the Nomad™ cordless portable power cleaner you can leave the outdoors where you found it.

With 3.5 gallons of mud-blasting, dirt-rinsing, scum-eliminating power, the Nomad makes quick work of just about any mess you can find out there.

Keep ATV's looking like new.

Clean game after the hunt.

Wash the trail off bikes.

Spray down gear, pets, and cookware.

Rinse off the boat, the tackle, and the fish.



# PORTABLE POWER CLEANER

## User Adjustable Spray Nozzle

Adjusts from a 90 PSI jet stream for power cleaning to a soft mist for washing the duck pond off your four-legged hunting buddy.

## Detachable Tank

Separate the 3.5 gallon tank from the base and dunk into lake or stream. Of course you could fill-up at a faucet, but it's just not as fun.

## 18 Volt Rechargeable Battery and Charger

Delivers enough power to run through 3 full tanks of water on a single charge, so you can clean a mess anywhere you make it.

## 12 Volt Power Port Option

Delivers a constant source of power for ON THE GO™ cleaning.

## Zippered Storage Pouch

Built-in neoprene pouch is durable and flexible. It's like a tackle box for your cleaning accessories.

## Built-in Filter

How is anything going to get cleaned with dirty water, it won't. So the filter catches it before it even leaves the nozzle.

## Over-Molded Handle, Cap and Spray Nozzle, Plus a Padded Shoulder Strap

It's all about the comfort.

## Swiveling Hose Quick Connect


Makes connecting a snap and will keep the 20-foot abrasion-resistant hose from kinking and twisting.



Available in orange MCOR35C and green MCOR35GRC

## Extra Batteries Available

For really big messes or longer times between charging, pick up an extra battery: MN100



# READY TO USE

## In Three Quick Steps

### 1. Fill Up

Remove the tank from the base, unscrew the cap and make sure the filter is in place. Fill with up to 3.5 gallons of clean water, replace the cap and snap the tank back into place.



### 2. Make The Connection

Pull back the quick disconnect on the hose. Push the quick disconnect into the hose connect and release. Check to make sure the hose is securely attached. Repeat steps to connect the other end of the hose into sprayer handle.



### 3. Give It Power

Using the battery:  
Insert the battery into the battery compartment door, accessible from the recessed center section. Includes storage space for an extra battery.



Using the power cord/adaptor:  
Attach the power cord to the unit by pushing it firmly into the power cord connect, then plug the adaptor end of the cord into any 12 V receptacle such as a vehicle cigarette lighter or power port.

