



Instruction Manual

Mini Tower Fan



It is important that you read these instructions before using your new fan and we strongly recommend that you keep them in a safe place for future reference.


Model No. SF-1530I (w/ ion)

Model No. SF-1530

IMPORTANT SAFETY MEASURES

- Please ensure that the voltage of the fan corresponds to the mains voltage.
- Use the fan only for the purpose defined in the user guide.
- Never insert your fingers, pencils or other objects through the cage during operation.
- Switch the fan off before moving or cleaning it.
- The fan should be set up on a stable and level surface to avoid it being knocked over.
- Do not expose the fan to excessive heat or humidity, as this can cause damage to the electrical components.
- Do not immerse in any form of liquid.
- It is not advisable to expose people, in particular babies and the elderly, to a continuous stream of cold air.
- The fan should be kept out of the reach of children.
- Ensure that the cable does not get caught beneath the device, in drawers, behind shelves etc.
- Do not run the cable under carpets, rugs, etc.
- Ensure that cable is kept away from busy areas to avoid anyone tripping over it.
- Do not use if the device or cable becomes damaged. Take it to a specialist for repair.
- For indoor use only.

OVERVIEW OF FUNCTIONS



1. Upper section
2. Base
3. Speed button
4. Speed indicator
5. Off button
6. Oscillation button
7. Oscillation indicator
8. Timer button
9. Timer indicator
10. Stand-by light

USE

WARNING:

In order to reduce the risk of fire or electrical shock, never use the appliance together with electronic timer.

As long as the device is connected to the power supply, the stand by light will remain on.

Speed:

Use the speed button to select speed.

The fan can be switched off again by pressing the off button.

Pressing the speed button repeatedly will alternate between the 3 speed options.

The speed indicators will show which speed has been selected (“LOW”, “MED” or “HI”).

Timer:

To use the timer function, first switch on the fan by selecting a speed.

You can then press the timer button to choose whether the fan is to switch off automatically after 1, 2 or 4 hours.

The timer indicators will show which timer setting has been selected (“1H” = 1 hour, “2H” = 2 hours or “4H” = 4 hours).

Oscillation:

Press the oscillation button to start and stop the fan moving from side to side.

The oscillation indicator comes on when oscillation has been selected.

Ionizer:

Ionizer automatically turned on when the fan is on. (on model #SF-1530I)

CLEANING

Always switch the fan off and unplug it before cleaning.

Clean the plastic parts using a damp cloth and a mild detergent, and ensure that all detergent residues are removed.

Never use abrasive cleaning agents or solvents.

Do not immerse in any form of liquid.

THE GUARANTEE DOES NOT APPLY

If the instructions give above are not observed

If the appliance has been mishandled, subjected to rough treatment, or has suffered any other form of damage.

For faults that may have arisen as a result of faults in your electricity supply.

If the appliance has been subject to unauthorized repairs.

Due to the constant development of our products in terms of function and design, we reserve the right to make changes to the product without prior warning.

SPECIFICATION

Model No.	Power consumption	Dimension (inches)	Weight
SF-1530	40W/60Hz/120V	7.1(L) x 6.1(W) x 15.8(H)	4.84lbs
SF-1530I	40W/60Hz/120V	7.1(L) x 6.1(W) x 15.8(H)	4.84lbs

DEFECTIVE NOTICE

If this product is defective or not working properly

Please DO NOT return to your retail store

Please contact us directly with any Service or Technical Assistance

Contact us toll free at:

1-800-330-0388



TOWER FAN

Your Guarantee

Three Year Limited Warranty on Motor and One Year Limited Warranty on All Other Parts. This guarantee is subject to the following terms:

SPT_{USA}, must be notified of the fault.

Proof of purchase must be presented to SPT_{USA}'s nominated representative.

The warranty will be void if the product is modified, misused or repaired by an unauthorized person.

The guarantee after repair or replacement will not be extended beyond the original one year period.

All replacement parts or units will be new or reconditioned. Parts or units, which are replaced, become the property of SPT_{USA}.

The warranty applies to the use of this product in the United States. Freight charge is not included in the warranty.

This GUARANTEE is in addition to your Statutory Rights.

Sunpentown Int'l Inc.

1-800-330-0388 www.spt-usa.com

Dear Customer: Please keep this warranty for your record. **DO NOT** return it.

